

INVERTER ZVF11-M/S Series  
User's Manual



## Foreword

- Thank you for your purchase of the ZVF11-M/S Series inverter
- This manual introduces the installation, operation, function setting, troubleshooting and etc. of the inverter ZVF11-M/S series.
- Incorrect installation or use may result in damage or other accidents. Do read all instructions in detail before installing or operating.
- Please forward this manual to the end user, and keep it handy for quick reference.
- If there are any doubts or questions, please contact the Technical Service Center of the Company.

## Table of Contents

<b>Chapter 1 Safety Instruction</b> .....	1
1.1 Safety Symbols and Definitions .....	1
1.2 Cautions for Use .....	2
1.3 Cautions for Operating Ambient.....	3
<b>Chapter 2 Introduction to the Product and Installation</b> .....	4
2.1 Product Inspection upon Arrival.....	4
2.2 Demonstration of the Model .....	4
2.3 Demonstration of the Nameplate .....	4
2.4 Specification and Technical Indications .....	5
2.5 Installing and Wiring .....	6
<b>Chapter 3 Instructions for use of the product and specification for parameters</b> .....	13
3.1 Operation Panel Specification .....	13
3.2 Function Parameters List .....	16
3.3 Function Parameters Specification .....	30
<b>Chapter 4 Trouble Indication and Troubleshooting</b> .....	57
4.1 Trouble Indication and Malfunction Causes .....	57
4.2 Common Troubleshoot .....	58
<b>Chapter 5 Inspection and Maintenance</b> .....	59
5.1 Inspection and Maintenance .....	59
5.2 Replacement of Wearing Parts .....	61
5.3 Storage of Inverter .....	61





## Table of Contents

<b>Chapter 6 Outline Dimension &amp; Mounting Dimension</b> .....	62
6.1 Inverter Outline Dimension & Mounting Dimension .....	62
6.2 Operation Panel Outline Dimension .....	63
<b>Appendices</b> .....	64
Appendix 1 Quality Warranty .....	64
Appendix 2 Optional Parts .....	65
Appendix 3 User's Parameter Amendment Record .....	67
Appendix 4 Warranty .....	70

## Chapter 1 Safety Instructions

### 1.1 Safety Symbols and Definitions

The safety instructions described in this manual are very important. To avoid any error that may result in damage to equipment, injury to personnel or loss of property, do read and clearly understand all of the safety symbols, symbol definitions and be sure to observe the indicated safety instructions below.

Safety Symbols	Symbol Definitions
 <b>HAZARD</b>	This symbol indicates hazardous HIGH VOLTAGE. Any incorrect operation may result in serious damage to the equipment or death to personnel.
 <b>WARNING</b>	This symbol indicates that any incorrect operation can result in damage to the equipment or minor to moderate injury to personnel.
 <b>CAUTION</b>	This symbol calls your attention to follow the instructions while in operation or in use.
 <b>TIP</b>	This symbol calls your attention to some useful messages for the user.



**HAZARD**

- Do not touch the circuit board or the parts when the power or the charge indicator is still on.
- Do not perform the work of wiring or inspecting the parts or signal of the circuit board unless the power supply is completely off.
- Do not dismount or change the connecting wires, circuits or parts inside the inverter by yourself.
- Do connect the inverter's earth terminal to the ground properly and tightly.



**WARNING**

- Do not perform withstand voltage test on the internal parts of the inverter because semiconductor parts can be easily damaged by the voltage.
- Do not connect the output terminal U, V or W of the inverter to the terminal L or N of AC power supply.
- Do not touch the main circuit board of the inverter because its CMOS and IC are vulnerable to static damage.

## 1.2 Cautions for Use

Before power transmission



**WARNING**

- Be sure the power supply and voltage selected should be equivalent to the input voltage of the inverter.



**WARNING**

- Be sure to install the inverter on metallic or other inflammable materials to avoid fire.
- Be sure to install a fan if several inverters are put in one cabinet, so that the temperature inside the cabinet is always below 40°C, thus overheating or fire can be prevented.
- Be sure not to dismount or install the operation panel and avoid failure or no display of the panel due to loose contact.

During power transmission



**HAZARD**

- DO NOT insert or pull the connecting lines of the inverter to avoid damage of the control panel caused by surge that enters the panel.

During operation



**HAZARD**

- DO NOT insert or isolate the motor during operation. Otherwise, it may cause overcurrent protection or even result in burnout of the main circuit of the inverter.
- KEEP CLEAR to avoid danger if self-priming (automatic start) is set which can restart automatically after the motor stops.
- DO NOT remove the terminal cover to prevent possible electric shock and injuries.

## 1.3 Cautions for Operating Ambient



direct exposure  
to sunlight



corrosive gas or liquid



oil or gas



Salt



high humidity (>90%)  
caused by rain or water  
drop



iron filings or powder



high vibration



extreme cold



Heat



EMI, ultrahigh pressure  
(i.e., electric welding line)



radioactive substances



inflammable  
substances

## Chapter 2 Introduction to the Product and Installation

## 2.1 Unpacking and Inspection upon Arrival

This product is guaranteed a high level of quality with strict outgoing inspection, crushproof and shockproof packaging. But this does not preclude damage to the product due to heavy collision or strong extrusion. So it is necessary to unpack the inverter upon arrival and perform these steps:

- ① Check whether there is a deformed or damaged casing; or any shattered component.
  - ② Check the nameplate of the inverter and make sure it matches the product part number you've ordered.
- If there is any problem with the above-mentioned contents, please contact with the supplier or manufacturer immediately.

## 2.2 Demonstration of the Model




Figure 2-1 Inverter Model Demonstration

## 2.3 Demonstration of the Nameplate




Figure 2-2 Specifications Label

2.4 Specifications and Technical Indications

Input Voltage Class		220V			
ZVF11-M/S_ _ _		0004S2	0075S2	0015S2	0022S2
Applicable Motor Power (KW)		0.4	0.75	1.5	2.2
Output	Output Current(A)	2.3	4.5	7.5	10.0
	Maximum Output Voltage(V)	Corresponding Three-phase Input Voltage			
	Range of Output Frequency(Hz)	0.01~400.00Hz			
Input	Range of Input Voltage	160~240V			
	Range of Input Power Frequency	50±5%Hz			
Control Characteristics	Control Mode	SAPWM Space Vector Control			
	Frequency Resolution	Figure Setting: 0.01Hz. Analog Setting: Maximum Frequency*0.1%			
	Torque Characteristics	Adjustable from 0% to 20%.			
	Overload Capacity	150% of the rated output current per minute			
	Acceleration/Deceleration time	Adjustable from 0.1 to 999.9.			
	V/F Curve	Linear/ Quadratic			
Running Characteristics	Frequency Setting Signal	Panel Control	Set by the key ▲▼ or the potentiometer on the panel.		
		External Signal	Terminal 0~10V, 4~20mA, 0~10KHz, UP/DOWN. 485 COM etc.		
	Operation Setting Signal	Panel Control	Set by the key RUN or STOP.		
		External Signal	External FWD, REV and JOG operation, PLC operation and COM operation.		
	Multi-function Input Signal	Multi phase speed, counter, program run, VI/CI shifting and etc.			
	Multi-function Output Signal	Failure, running, counter arrival, frequency arrival program running			
	Analog Output Signal	Running frequency, output voltage, current, motor rotation			
Other Functions	AVR, overvoltage and current stall prevention, no reversal and etc.				
Protecting Functions	Overvoltage, overcurrent, undervoltage, overload, overheat, short circuit protection and etc.				
Cooling Mode	Forced air cooling				
Ambient	Points of Use	Altitude < 1000m, indoor places without corrosive gas, liquid and etc.)			
	External Environment	Temperature: -10~+45°C; Humidity < 90%RH without condensing			
	Vibration	< 0.5G			

2.5 Installation and Wiring

2.5.1 Operating Environment:

The Inverter mounting ambient have direct effect on the function and lifetime of inverter. So the ambient have to reach the following situation:  
 Altitude: Maximum 1000m above sea level  
 Ambient Temperature: -10~+45C [Bare Machine: -10~+50C ]  
 Humidity: 20~90% RH (Non-condensing)  
 Ambient: Indoor places free from direct exposure to sunlight, dust, corrosive gas, flammable gas, oil mist, steam, drip and salt.  
 Vibration: < 0.5G

2.5.2 Installation Space and Direction

To get better cooling effect and for the convenience of maintenance, the inverter shall be installed vertically with enough space left (refer to Fig.2-3). When two or more inverters are fixed in the same cabinet, it is recommended to fix them in parallel and horizontally to reduce heat produced by them (refer to Fig.2-4). When there is a must to fix them up and down, please fix an insulating board between them so that the heat produced by the lower one could not have direct influence on the upper one (refer to Fig.2-5).




Fig.2-3 Diagram of Installation Space




Fig.2-4 Diagram of Multi-piece Parallel Installation




Fig.2-5 Diagram of Multi-piece Vertical Installation



**WARNING**

- Be sure the main loop terminals should be connected to the cable tightly. Otherwise, the inverter may be damaged arising from loose connection.
- Be sure the ground terminals of the inverter and the motor must be properly grounded. Multi-piece inverter should be grounded on one shared point.
- Be sure to install an non-fuse circuit breaker or leakage protective circuit breaker in the inverter's input port to prevent expanding of accident due to inverter problem.

2.5.3 Inverter's Standard Wiring Diagram





Fig. 2-6 Basic System Description on Wiring

2.5.4 Instructions for Main Circuit Terminals

1. Diagram of Main Circuit Terminals



Single phase 220V powerinput  
Fig.2-7 Input Terminals




Fig.2-8 Output Terminals

2、Description on Main Circuit Terminals


Terminal Symbol	Function Description
L、N	Power input terminals connecting to single-phase 220V AC power supply
U、V、W	Inverter output terminals connecting to three-phase AC motor
P、DB	External braking resistance terminals connecting to both ends of the external braking resistor.
⏏ G	Ground terminal or ground wire.



- The input power terminals don't differ on phase sequence and can be connected arbitrarily.
- If the motor counter rotates (reverses) when the output terminals U, V and W connect to three-phase motor, just exchange two phases of U, V and W arbitrarily.



- The inverter's ground lead cannot connect to the ground together with other heavy current load, but connect to the ground separately. The shorter of the ground line is, the better it is.
- The ground terminal is required to have a tight ground contact to avoid electric shock fire and reduce noise. Don't form a loop if several inverters connect to the ground together. Refer to the figure below



- The diameter of the ground line must conform to the state standards.
- Make sure the excellent connection. Please use the terminal with insulating pipe to connect the terminal with lead.
- After wiring is finished, check carefully if there is any foreign matter come into the inverter. Confirm all the connection lines are proper without any missing or wrong connection. Be sure there is no short circuit between terminals and connection lines, or short circuit to earth.

2.5.5 Description of Control Circuit Terminals

1、Diagram of Control Circuit Terminals




Fig.2-9 Control Terminals

2、Description of Control Circuit Terminals

Types	Terminal Symbols	Function Description	Electrical Specifications
Public Port	COM	Numeral Signal Public Terminal	
Multi-function Input Terminal	X1	Valid only when there is a short-circuit between Xn (n=1, 2, 3, 4, 5, 6) and COM. The functions can be set by parameter F3.00~F3.05 separately.	INPUT, 0~24V power level, low level valid, 5mA
	X2		
	X3		
	X4		
	X5		
	X6		
Power Supply	24V	24VDC Power Output (Control Power)	24VDC/100mA
Multi-function Output Terminal	Y1	Multi-function open-collector output is defined as on-off output terminal, whose function is set by the parameter F3.09 with reference of COM	OUTPUT Maximm load current ≤ 50mA
Public Port	GND	Analog Signal Public Terminal	
Analog Input Terminal	10V	External analog preset power supply	OUTPUT, 10VDC Voltage
	AVI	Analog voltage signal input, with reference of GND.	INPUT, 0~10VDC Voltage
	ACI	Analog current signal input, with reference of GND	INPUT, 0~20mA DC Current
Analog Output Terminal	AFM	Analog voltage current output with reference of GND.	OUTPUT, 0~10V (0~20mA)



Types	Terminal Symbols	Function Description	Electrical Specifications
Multi-function Relay Output Terminal	TA	Set by the parameter F3.08. Normal: TA-TB closed Failure: TA-TC closed	Contact capacity: NO 250VAC/5A NC 250VAC/3A
	TB		
	TC		
COM Terminal	SG+	Communication Signal Positive Terminal	
	SC-	Communication Signal Negative Terminal	




- The connecting wire of control circuit must be STP (shielded twisted pair wire) which should be separated from the main circuit and strong current circuit. If the connecting wire of the control circuit had to pass through the main circuit and other control wires, they must intersect at an angle of 90°.
- The control circuit is liable to external interferences. So the length of the wire should be short as possible. Usually, it can not exceed 30m. When used for analog voltage, current or potentiometer input, the wire should not exceed 20m in length.
- To avoid loose contact, a tight contact is recommended when taking a joint as input.
- To remove malfunction of surge voltage on the inverter's control circuit and peripheral equipment, a surge absorber should be installed to connect two ends of the magnetic coil that has generated surge voltage.
- The diameter of the control circuit wire is recommended to be 0.75mm<sup>2</sup>.

2.5.6 Schedule of Matching Electrical Products

Model ZVF11	Maximum Applicable Motor (KW)	Main Circuit Diameter mm <sup>2</sup>	Circuit Breaker (A)	Contactor (A)
-M/S 0004S2	0.4	2.5	10	10
-M/S 0007S2	0.75	2.5	10	10
-M/S 0015S2	1.5	4.0	16	16
-M/S 0022S2	2.2	4.0	20	25

2.5.6 Diagram of Wiring for Inverter System & Cautions for Wiring



### Chapter 3 Instructions for use of the product and specification for parameters

#### 3.1 Specification for Operation Panel

##### 3.1.1 Operation Panel Outlay




Fig.3-1 Diagram for ZVF11-W/S Operation Panel

##### 3.1.1 Description on Keys

Symbol	Key Name	Function Description
<b>MODE</b>	Mode key.	Press this key to enter into the function programming mode. Once parameters are modified, press this key to exit the function programming mode.
<b>SET</b>	Confirm key.	In the state of programming, press this key to confirm the function code. After parameters are modified, press this key to save modified data. In an operation or hold mode, press this key to shift the displaying content, such as output frequency, current, revolution.
<b>▲</b>	Up key.	In the state of programming, the function code and parameter value will go up by pressing this key. In an operation or hold mode, press this key to increase the operation frequency.
<b>▼</b>	Down key.	In the state of programming, pressing this key, the function codes and parameter value will go down. In an operation or hold mode, press this key to decrease the operation frequency.
<b>RUN</b>	Run key.	Pressing this key, the inverter begins to run. If "F0.02" is set to "External Terminal Control", then it is invalid to press this key.
<b>STOP RESET</b>	Stop/Reset key.	Pressing this key, the inverter stops. If "F0.02" is set to "External Terminal Control", then it is invalid to press this key. When a failure alarm occurs, press this key to reset the system. In the state of programming, press this key to realize data traverse.

##### 3.1.2 Description on LED Indicator Lights

LED Symbol	Name	Description
<b>RUN</b>	Run Indicator	This Light turns ON when the inverter runs.
<b>STOP</b>	Stop Indicator	This Light turns ON when the inverter stops.
<b>FWD</b>	Forward Indicator	This Light turns ON when the inverter forwards.
<b>REV</b>	Reverse Indicator	This Light turns ON when the inverter reverses.



The LED displays -VF- when the inverter is energized.


- In the operation or hold mode, pressing ▲ ▼, the frequency value can be modified when it is set by Up/Down key ▲ ▼ on the panel (F0.01=1).
- In the operation or hold mode, pressing SET, the display can shift to the output frequency, current, rotating speed and etc.
- In the state of operation, the stop function of the STOP/RESET key is prior to the reset function, i.e., to modify a parameter when the inverter is in operation, pressing this key, the inverter will stop running. (Note: The operation mode is set to "Panel Control".)

## 3.1.2 Use of the Operation Panel


- 1、 Change the frequency set mode from ▲▼ control to external voltage (0~10V) control.



2. Change the acceleration time from 10.0s to 20.0s.



3. Restore all the parameters to Factory Default Settings



## Notes

- indicates the data tube flickers; indicates the tube doesn't flicker.
- To modify parameters when the inverter is in operation, the inverter will stop running when pressing the **STOP/RESET** key (Note: the operation mode is set to "Panel Control".)
- To modify parameters when the inverter is in operation, please pay attention to the modification right because some parameters can not be modified in the operation mode.
- If parameters cannot be modified in the hold mode, please check whether the parameters are locked or not (Fc.12=1).

## 3.2 List of Function Parameters

## F0 series Basic Parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F0.00	Keyboard setting frequency	0.0~400.0Hz	0.1Hz	5.0Hz	
F0.01	Frequency setting mode	0: Keyboard or terminal setting by pressing UP/DOWN 1: Keyboard potentiometer setting 2: External analog voltage setting 3: External analog current setting 4: Combined multi-stage speed setting 5: External terminal high/low speed setting (AVI) 6: External impulse input setting 7: PID setting 8: 485 COM setting 9: Terminal A/I/ACI setting	1	1	
F0.02	Operation command selection	0: Keyboard control 1: Terminal control 2: Multi-stage speed control 3: External analog voltage input control 4: External analog current input control 5: 485 COM control	1	0	
F0.03	Stop mode	0: Free stop 1: Decelerated stop	1	1	
F0.04	Basic frequency	40.0~400.0Hz	0.1Hz	50.0Hz	
F0.05	upper limiting frequency	0.0~400.0Hz	0.1Hz	50.0Hz	
F0.06	lower limiting frequency	0.0~400.0Hz	0.1Hz	0.0Hz	
F0.07	Acceleration time	0.1~999.9s	0.1s	10.0s	
F0.08	Deceleration time	0.1~999.9s	0.1s	10.0s	
F0.09	Starting frequency	0.0~40.0Hz	0.1Hz	0.5Hz	
F0.10	Starting holding time	0.0~60.0s	0.1s	0.0s	
F0.11	Shutdown frequency	0.0~40.0Hz	0.1Hz	0.0Hz	
F0.12	Frequency fine tuning	0.00~0.09Hz	0.01Hz	0.00Hz	

### Chapter 3 Instructions for use of the product and specification for parameters

#### F0 series Basic Parameters(Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F0.13	Jog frequency	0.5-400.0Hz	0.1Hz	5.0Hz	
F0.14	Jog acceleration time	0.1-999.9s	0.1s	10.0s	
F0.15	Jog Deceleration time	0.1-999.9s	0.1s	10.0s	

#### F1 series Control Parameters(Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F1.00	FWD/REV command selection	0: No reversing 1: Keyboard selection 2: External terminal selection 3: 485 COM selection	1	0	
F1.01	Keyboard operating direction	0: Forward 1: Reverse	1	0	
F1.02	FWD/REV shifting time	0.0-60.0s	0.1s	0.0s	
F1.03	V/F curve setting	0: Linear type (constant torque load) 1: Square type (fan, pump) 2: Polygonal type (F1.04, F1.05)	1	0	
F1.04	IF setting	10.0Hz-40.0Hz (Valid when F1.03=2)	0.1Hz	30.0Hz	
F1.05	IF output voltage setting	20.0Hz-100.0% (Valid when F1.03=2)	0.1%	60.0%	
F1.06	Acceleration S curve setting	0-7 (Valid when acceleration time < 10s)	1	0	
F1.07	Deceleration S curve setting	0-7 (Valid when deceleration time < 10s)	1	0	
F1.08	Leap frequency range	0.0-10.0Hz	0.1Hz	0.0Hz	
F1.09	1st leap frequency	0.0-400.0Hz	0.1Hz	0.0Hz	
F1.10	2nd leap frequency	0.0-400.0Hz	0.1Hz	0.0Hz	
F1.11	3rd leap frequency	0.0-400.0Hz	0.1Hz	0.0Hz	
F1.12	Carrier frequency	1000-9999Hz	1Hz	5000Hz	

### Chapter 3 Instructions for use of the product and specification for parameters

#### F1 series Control Parameters(Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F1.13	Torque lifting	0.0-20.0%	0.1%	8.0%	
F1.14	Output voltage regulating	50%-100%	1%	100%	

#### F2 series Braking and Braking Displaying Parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F2.00	Starting DC braking time	0.0-100.0s	0.1s	0.0s	
F2.01	Starting DC braking voltage	0-100V	1V	20V	
F2.02	Shutdown DC braking time	0.0-100.0s	0.1s	0.0s	
F2.03	Shutdown DC braking voltage	0-100V	1V	20V	
F2.04	Braking enable	0: Invalid 1: Valid	1	1	
F2.05	Braking inception voltage coefficient	100%-170%	1%	140%	
F2.06	Braking termination retard coefficient	0%-20%	1%	5%	
F2.07	Display mode 1	0: Frequency display 1: Output current 2: Input voltage 3: Output voltage 4: Motor rotating speed	5: Count input value 6: AVI feedback value 7: ACI feedback value 8: PID setting value 9: PID feedback value	0	
F2.08	Display mode 2		1	1	
F2.09	Display mode 3			2	

#### F3 Series Multi-function port parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F3.00	Terminal X1 function selection	0: Invalid 1: Combined multi-stage speed 1 2: Combined multi-stage speed 2	1	1	
F3.01	Terminal X2 function selection			2	

F3 Series Multi-function portparameters (Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F3.02	Terminal X3 function selection	3: Combined multi-stage speed 4: Combined accelerating/decelerating time 5: Combined accelerating/decelerating time 2 6: Forward operation (FWD) 7: Reverse operation (REV) 8: RUN 9: Running direction selection (forward or reverse) 10: JOG forward 11: JOG reverse 12: Reset (RST) 13: Counter reset 14: Counter Up input 15: Counter Down input 16: External impulse input 17: Pulse enable 18: Frequency increasing (UP) 19: Frequency decreasing (DOWN) 20: External fault 21: PLC pulse start 22: PLC pulse stop 23: Three-wire FWD control 24: Three-wire REV control 25: Three-wire NO shutdown control 26: Three-wire NC shutdown control 27: External free shutdown input 28: External decelerated shutdown input 29: Analog frequency command selection (AVI/ACI) 30: Terminal high/low speed selection	1	3	
F3.03	Terminal X4 function selection			6	
F3.04	Terminal X5 function selection			7	
F3.05	Terminal X6 function selection			12	
F3.06	Output target frequency setting	0.2-400.0Hz	0.1Hz	50.0Hz	
F3.07	Frequency detection range	0.0-50.0Hz	0.1Hz	0.0Hz	

F3 Series Multi-function portparameters (Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F3.08	Relay function selection	0: Invalid 1: Fault output 2: Target frequency arrived 3: Set frequency arrived 4: Operation output 5: Counter arrived 6: upper limiting frequency arrived 7: lower limiting frequency arrived 8: Program operating indication	1	0	
F3.09	Y1 function selection			0	

F4 Series Multi-stage SpeedParameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F4.00	Multi-stage speed 1	0.0-400.0Hz	0.1Hz	10.0Hz	
F4.01	Multi-stage speed 2	0.0-400.0Hz	0.1Hz	20.0Hz	
F4.02	Multi-stage speed 3	0.0-400.0Hz	0.1Hz	30.0Hz	
F4.03	Multi-stage speed 4	0.0-400.0Hz	0.1Hz	40.0Hz	
F4.04	Multi-stage speed 5	0.0-400.0Hz	0.1Hz	50.0Hz	
F4.05	Multi-stage speed 6	0.0-400.0Hz	0.1Hz	60.0Hz	
F4.06	Multi-stage speed 7	0.0-400.0Hz	0.1Hz	70.0Hz	
F4.07	1st accelerating time	0.1-999.0s	0.1s	10.0s	
F4.08	1st decelerating time	0.1-999.0s	0.1s	10.0s	
F4.09	2nd accelerating time	0.1-999.0s	0.1s	10.0s	
F4.10	2nd decelerating time	0.1-999.0s	0.1s	10.0s	
F4.11	3rd accelerating time	0.1-999.0s	0.1s	10.0s	

F4 Series Multi-stage SpeedParameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F4.12	3rd decelerating time	0, 1-999, 0s	0.1s	10.0s	
F4.13	4th accelerating time	0, 1-999, 0s	0.1s	10.0s	
F4.14	4th decelerating time	0, 1-999, 0s	0.1s	10.0s	
F4.15	Acceleration/Deceleration source selection	0: Keyboard setting 1: Terminal selection	1	0	

F5 Series Protection FunctionParameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F5.00	Undervoltage protection	0: Disabled 1: Enabled	1	1	
F5.01	Undervoltage Protection Voltage Proportion	50%-100%	1%	60%	
F5.02	Over-voltage protection Function	0: Disabled 1: Enabled	1	1	
F5.03	Over-voltage protection voltage proportion	100%-150%	1%	135%	
F5.04	Over-voltage stall function	0: Disabled 1: Enabled	1	1	
F5.05	Over-voltage stall voltage proportion	100%-150%	1%	125%	
F5.06	Over-current stall function	0: Disabled 1: Enabled	1	1	
F5.07	Stall current proportion	100%-150%	1%	150%	
F5.08	Overload protection	0: Disabled 1: Enabled	1	1	
F5.09	Overload current proportion	10%-200%	1%	150%	
F5.10	Overload protection time	0-120s	1s	60.0s	
F5.11	Overheat function	0: Disabled 1: Enabled	1	1	
F5.12	OP trip function	0: Disabled 1: Enabled	1	0	

F6 series Communication andFault Parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F6.00	485 COM Mode	0: 8-N-1, 8-bit data, 1 bit stop, no parity RTU 1: 8-E-1, 8-bit data, 1 bit stop, even parity RTU 2: 8-0-1, 8-bit data, 1 bit stop, odd parity RTU 3: 8-N-2, 8-bit data, 2-bit stop, no parity, RTU 4: 8-E-2, 8-bit data, 2-bit stop, even parity, RTU 5: 8-0-1, 8-bit data, 2-bits stop, odd parity, RTU 6: 7-N-1, 8-bit data, 1-bit stop, no parity, ASCII 7: 7-E-1, 8-bit data, 1-bit stop, even parity, ASCII 8: 7-0-1, 8-bit data, 1-bit stop, odd parity, ASCII 9: 7-N-2, 8-bit data, 2-bit stop, no parity, ASCII 10: 7-E-2, 8-bit data, 2-bit stop, even parity, ASCII 11: 7-0-2, 8-bit data, 2-bit stop, odd parity, ASCII 12: 8-N-1, 8-bit data, 1-bit stop, no parity, ASCII 13: 8-E-1, 8-bit data, 1-bit stop, even parity, ASCII 14: 8-0-1, 8-bit data, 1-bit stop, odd parity, ASCII 15: 8-N-2, 8-bit data, 2-bit stop, no parity, ASCII 16: 8-E-2, 8-bit data, 2-bit stop, even parity, ASCII 17: 8-0-2, 8-bit data, 2-bit stop, odd parity, ASCII	1	0	

### Chapter 3 Instructions for use of the product and specification for parameters

#### F6 series Communication and Fault Parameters (Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F6.01	485 COM baud rate selection	0: 1200bps 3: 9600bps 1: 2400bps 4: 19200bps 2: 4800bps 5: 38400bps	1	0	
F6.02	485 COM local address	1-127	1	1	
F6.03	Communication error report	0: Disabled 1: Enabled	1	0	
F6.04	Error-recoverable times	0-5	1	0	
F6.05	Error recovering time	5-600s	1s	60s	
F6.06	Last error type	0-14	1	For search	
F6.07	Next-to-last error type	0-14	1	For search	
F6.08	Antepenultimate error type	0-14	1	For search	

#### F7 Series PID Function Parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F7.00	PID setting source selection	0: Keyboard set, AVI feedback 1: Keyboard set, ACI feedback 2: Keyboard potentiometer set, AVI feedback 3: Keyboard potentiometer set, ACI feedback 4: AVI set, ACI feedback 5: ACI set, AVI feedback	1	0	
F7.01	PID digital set	00.0-100.0	0.1	50.0	
F7.02	PID upper limiting frequency	10.0-400.0	0.1Hz	50.0Hz	
F7.03	PID lower limiting frequency	10.0-400.0	0.1Hz	10.0Hz	

### Chapter 3 Instructions for use of the product and specification for parameters

#### F7 Series PID Function Parameters (Continued)

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F7.04	PID feedback selection	0: Positive feedback 1: Negative feedback	1	0	
F7.05	Proportional gain Kp	00.0-100.0	0.1	1.0	
F7.06	Integral time Ki	0.0-100.0s	0.1s	0.0s	
F7.07	Differential time Kd	0.0-100.0s	0.1s	0.0s	
F7.08	PID tolerance range	0.0-20.0%	0.1%	1.0%	
F7.09	PID detection time	0.1-60.0s	0.1s	1.0s	
F7.10	Sleep time	0.0-60.0s	0.1s	0.0s	
F7.11	Frequency wake-up threshold	1.0-100.0Hz	0.1Hz	10.0Hz	
F7.12	Encoder speed setting	1-9999	1	2400	
F7.13	Encoder impulse times per week	1-2000	1	1024	
F7.14	Reserved function				

#### F8 Series Analog Input/Output Parameters

Function Code	Name	Range of setting	Minimum Unit	Factory Default Setting	Note
F8.00	Maximum voltage value for analog voltage input	0.0-10.0V	0.1V	10.0V	
F8.01	Minimal voltage value for analog voltage input	0.0-10.0V	0.1V	0.5V	
F8.02	Frequency that corresponds to the maximum voltage for analog input	0.0-400.0Hz	0.1Hz	50.0Hz	
F8.03	Frequency that corresponds to the minimal voltage for analog input	0.0-400.0Hz	0.1Hz	0.0Hz	
F8.04	Maximum current value for analog current input	0.0-20.0mA	0.1mA	20.0mA	
F8.05	Minimal current value for analog current input	0.0-20.0mA	0.1mA	4.0mA	